


| CHANNEL | EFFECT        |
|---------|---------------|
| 1       | STOP / STROBE |

• **STOP / STROBE - channel 1**



| BIT       | %          | EFFECT  |
|-----------|------------|---|
| 244 - 255 | 95.5 - 100 | OPEN  |
| 243       | 95.0       | FAST STROBE (2 flash/sec)                               |
| 140       | 54.7       | SLOW STROBE (1 flash/4 sec)                             |
| 139       | 54.2       | THE BANDS ARE PROGRESSIVELY OBSCURED FROM RIGHT TO LEFT |
| 65        | 25.5       | THE BANDS ARE PROGRESSIVELY OPENED FROM RIGHT TO LEFT   |
| 64        | 25         | THE BANDS ARE PROGRESSIVELY OPENED FROM RIGHT TO LEFT   |
| 7         | 3.0        | CLOSED  |
| 0 - 6     | 0.0 - 2.5  | CLOSED  |